

Sensor Suites



Vantage Vue Sensor Suite

Because Vantage Vue's transmitters are radio-compatible with Vantage Pro2, you can mix and match components. The sensor suite can transmit to Vantage Vue and wireless Vantage Pro2 consoles, wireless Weather Envoy and Vantage Connect. Mounting pole not included.

6357 Vantage Vue Sensor Suite



Vantage Pro2 Sensor Suite

Includes all the features of the Vantage Pro2 and Pro2 Plus sensor suites shown on page 8. Compatible with Vantage Vue and Vantage Pro2 consoles, Weather Envoy and Vantage Connect. Mounting tripod pole not included.

WIRELESS SENSOR SUITE

6322 with Standard Radiation Shield

6323 with 24-Hour Fan-Aspirated Radiation Shield

CABLED SENSOR SUITE*

6322C with Standard Radiation Shield



WIRELESS SENSOR SUITE PLUS with UV and Solar Radiation Sensors

6327 with Standard Radiation Shield

6328 with 24-Hour Fan-Aspirated Radiation Shield

CABLED SENSOR SUITE PLUS with UV and Solar Radiation Sensors*

6327C with Standard Radiation Shield



GroWeather® Sensor Suites FOCUS ON AGRICULTURE

6820 GroWeather Wireless with Solar Radiation Sensor and Standard Radiation Shield

6820C GroWeather Cabled with Solar Radiation Sensor and Standard Radiation Shield*



* Cabled sensor suites can only be used with a cabled Vantage Pro2 console, cabled Envoy, cabled Vantage Connect or EnviroMonitor, and include 100 ft. (30 m) cable.

All Vantage Vue and wireless Vantage Pro2 sensor suites can be used with Vantage Connect and wireless Weather Envoy.

All sensor suites are compatible with WeatherLink (see page 14).

Mounting tripod 7716 optional (see page 9).

Add special-purpose stations or sensors

Customize your Vantage Pro2 weather station, Vantage Connect or Weather Envoy by adding special-purpose stations and sensors. Each can receive data from up to eight different transmitting stations.



Wireless Leaf & Soil Moisture/Temperature Station (Solar-powered)

Includes a transmitter and backup battery inside a weather-resistant shelter. To view the data, add a wireless Vantage Pro2 console/receiver or Weather Envoy and WeatherLink. Vantage Pro2 console/receiver or Weather Envoy and WeatherLink can only receive data from either:

- A single fully-populated station with two Leaf Wetness Sensors, four Soil Moisture Sensors, and four Temperature Probes,
- OR**
- Two partially-populated stations, one with two Leaf Wetness Sensors and two Temperature Probes, and the other with four Soil Moisture Sensors and four Temperature Probes.

Available in two models. Choose the model without sensors (6345), and add only those you need to meet your requirements. Or choose the Complete Soil Moisture/Temperature Station (6345CS), and add one or two Leaf Wetness Sensors as desired. Compatible with the 6470 Stainless Steel Temperature Probe with 2-Wire Termination.

6345 Wireless Leaf & Soil Moisture/Temperature Station without sensors



6345CS Complete Soil Moisture/Temperature Station with 4 Soil Moisture Sensors and 4 Temperature Probes

